

About balancing

Adhesive weight installation instructions



1. Pre-treating the rim

Apply a suitable cleaning agent on the area where weight is to be applied. Wipe area clean and dry. Please note: Be sure to test the cleaning agent on a small area to ensure it will not damage the wheel's finish.



2. Select the correct adhesive weight size

Cut the adhesive weights or break them apart, depending on weight type, to obtain the correct amount of weight needed.



3. Applying the weights

Remove the tape backing and press the center of the weight exactly at the imbalance point. Please note: Do not touch the tape surface after peeling off the tape backing.



4. Securing the weight

Once the center of the weight is located at the imbalance point, press down on the full weight length working from the center to the left and right. Using firm hand pressure should be enough to secure the weight.

Perfect Equipment Inc.

1715 Joe B. Jackson Parkway | Murfreesboro, TN 37127
800-251-1566 | 615-893-0643 | Fax 615-898-1668

www.perfectequipment.com | [Privacy](#) | [Terms and conditions](#) | [Environmental policy](#)