

## Blade Conversion Chart

### R3 (4 SEGMENT) - 8.25" DIA

PINCOTT	B & J USA	B & J EUROPE	ITALMATIC	NORTE SUL
R3 - 25	R3 - 25	R3 - 25	I - 3 - 25	R - 3 - 25

### R4 (4 SEGMENT) - 9" DIA

PINCOTT	B & J USA	B & J EUROPE	ITALMATIC	NORTE SUL
R4 - 9	-	-	-	-
R4 - 16	R - 4 - 16	R - 4 - 15	I - 4 - 16	-
R4 - 20S	R - 4 - 20	-	Long Life II US	-
R4 - 20U	-	R - 4 - 20	Long Life II E	OMEGA / R4 - 23
R4 - 24	R - 4 - 24	R - 4 - 24	I - 4 - 24	-
R4 - 25	R - 4 - 25	R - 4 - 25	I - 4 - 25	-
SMART II	-	-	-	-
SMART IIE	-	-	-	-
ULTRA II	Apollo II	-	-	-
ULTRA IIE	-	Apollo IIIU	-	ALPHA
UD - II	-	-	-	-
CACTUS	R4 - Cactus	R4 - Cactus	-	-

### R105 (5 SEGMENT) - 10.5" DIA

PINCOTT	B & J USA	B & J EUROPE	ITALMATIC	NORTE SUL
R105 - 22	R - 105 - 22	-	I - 105 - 22	-
R105 - 25	-	-	-	R105 - 25

### R115/5 (5 SEGMENT) - 11.5" DIA

PINCOTT	B & J USA	B & J EUROPE	ITALMATIC	NORTE SUL
R115 - 20	R - 115 - 20	R - 115 - 20	I - 115 - 20	R115 - 23
R115 - 25	R - 115 - 25	R - 115 - 25	I - 115 - 25	R115 - 23
Smart I	-	-	-	-
Ultra I	Apollo I	-	-	-
R115	-	-	-	-
UD - I	-	-	-	-

### R115/6 (6 SEGMENT) - 11.5" DIA

PINCOTT	B & J USA	B & J EUROPE	ITALMATIC	NORTE SUL
P3 - 20	-	S - 115 - 20	Long Life IIIB	S115 - 23
P3 - 25	S - 115 - 25	S - 115 - 25	Long Life III	S115 - 23
Smart III	-	-	-	-
Ultra III	Apollo III	Apollo III	-	-

### Full Circle Rasp Blade

PINCOTT	B & J USA	B & J EUROPE	ITALMATIC	NORTE SUL
P6	R6	R6	I - 6	R6
P5	R5	R5	I - 5	R5

