

## About balancing

### Clip-On wheel weight installation instructions



#### 1. Select the correct application

Using a wheel weight application guide, select the correct application for the vehicle you are servicing. Check that the weight application is correct by testing the placement on the wheel flange.



#### 2. Placing the wheel weight

Place the wheel weight in the correct location of the imbalance. Prior to striking with the hammer, make sure that the top and the bottom of the clip are touching the rim flange. The body of the weight should not be touching the rim!



#### 3. Installation

Once the wheel weight is properly aligned, strike the clip with a proper wheel weight installation hammer. Please note: striking the weight body could result in clip retention failure or weight movement.



#### 4. Checking the weight

After installing the weight, check to make sure that it is secured properly.

#### Perfect Equipment Inc.

1715 Joe B. Jackson Parkway | Murfreesboro, TN 37127  
800-251-1566 | 615-893-0643 | Fax 615-898-1668

[www.perfectequipment.com](http://www.perfectequipment.com) | [Privacy](#) | [Terms and conditions](#) | [Environmental policy](#)